

IMPORTANT

The following Installation procedures are recommended by the product manufacturers – Ampelite Australia Pty Ltd.

These recommendations closely follow the Australian Standard: Design and Installation of Sheet Roof and Wall Cladding, Part 3: Plastic. AS1562.3:2006

INSTALLATION POINTERS

1. Loose lay metal sheeting in skylight location as a template, as per normal roof practice, achieving correct 700mm cover skylight location.
2. Remove steel roof sheet template
3. Slide ClearSlide clip into position on purlin, allowing the locating tab to touch male rib of the metal deck. (Note directional arrow on the clip)
4. Screw the clip into position using three roof Tek screws
5. Fix the finishing side clip over the metal male rib and Tek screw in through slot provided on the ClearSlide clip.
6. Using multi grips or pliers, crimp the finishing slide clip and steel male rib together
7. When fixing fibreglass ensure that the sliding saddle is centred to the rail markers
8. Lay ClearSlide Wonderglas GC fibreglass over the installed ClearSlide brackets.
9. Using a normal steel Tek screw fitted with a 32mm Weatherlok Washer, screw directly through the fibreglass into pre-punched hole on the saddle
- 10 Continue screwing sheets into place until ClearSlide System is complete